




CO. WASH. MAINTENANCE GENERAL NOTE:

HOA TO MAINTAIN DESIGN GRADES AND RIPRAP ALONG CUTOFF WALLS AFTER EVERY MEASURABLE STORM EVENT. IF THERE IS MEASURABLE RAINFALL DEPTH IN THE CORFED GAUGES 4329 AND 4344, THE CO. WASH SHOULD BE INSPECTED BY HOA AFTER CESSATION OF THE STORM EVENT.

CORFED RAINFALL GAUGE 4329 IS LOCATED IN BROWNSTONE CANYON UPSTREAM OF VILLAGE 24.

CORFED RAINFALL GAUGE 4344 IS LOCATED IN THE RED ROCK DETENTION BASIN DOWNSTREAM OF VILLAGE 24.

BASIS OF BEARINGS

SOUTH 89°47'23" EAST, BEING THE BEARING OF THE NORTH LINE OF SECTION 33, TOWNSHIP 20 SOUTH, RANGE 59 EAST, M.D.M., CITY OF LAS VEGAS, CLARK COUNTY, NEVADA AS SHOWN IN FILE 118, PAGE 100 OF PARCEL MAPS ON FILE AT THE CLARK COUNTY, NEVADA RECORDER'S OFFICE.

Call before you Dig
Avoid cutting underground utility lines. It's costly.


Call 811

1-800-227-2600

CLARK COUNTY PUBLIC WORKS
1-702-455-0000

AVOID HITTING OVERHEAD POWER LINES. IT'S COSTLY

CALL BEFORE YOU DIG OVERHEAD



1-702-227-2029

FAST

Call before you UnderGround

1-702-432-5300

PREMIER AND ARTISAN
CABLE MANAGEMENT
1.800.776.6766

