

1012 1000 988 976 964 952 940 928 916

893 Balzar Avenue
Major Cross Streets:
Revere Street//Lake Mead Blvd

1013 989 965 953 929 917
RCH
1000 988 976 974 952 916
CHURCH

893 887 863 863 857 851 845
892 886 880 874 870 866 858 850 844 838 832 821



BALZAR AVE

1013 989 965 953 941 929
CHURCH
012 988 984 964

893 887 881 875 863 857 839 827
CHURCH CHURCH
892 886 880 874 862 850 840 830 820

LA SALETTE ST

LAWRY AVE


1011 991 981 977 965 945
CHURCH
2122

887 881 875 863 857 851 843 827
2128
2124

893 Balzar Avenue
Major Cross Streets:
Revere Street//Lake Mead Blvd

COMMUNITY CENTER

10 UNITS
10 UNITS
OFFICE
10 UNITS



CHURCH

CHURCH
PARKING LOT

CHURCH
CHURCH

CH

CHURCH

BLANKENSHIP AVE

PARKING

CHURCH

W BARTLETT AVE

PARKING

CHURCH

CHURCH

BALZAR AVE

CHURCH

CHURCH

CHURCH

CHURCH

CHURCH

LAWRY AVE

GILDAY AVE

HASSELL AVE

CHURCH

CHURCH

HART AVE

CHURCH

AUTO CHURCH

SHOPS

PARKING

MATHESON ST

HAUSE AVE

VAN ERT AVE

REVERE ST

CONCORD ST

CONCORD ST

MULLER ST

MULLER ST

